



## **MI HK MP5 AND Clones Handguard's**

### **Installation Instructions.**

- 1.) Please make sure your firearm is unloaded and pointed in a safe direction.
- 2.) Remove factory handguard on your rifle
- 3.) Remove the M6.0 X 1.0 screw from your handguard with the supplied hex key.
- 4.) Loosen but do not remove the 8-32 low head screw's with the supplied hex key.
- 5.) Install the MI handguard onto your rifle or pistol.
- 6.) Apply blue thread loc onto the the M6 X 1.0 screw.
- 7.) Install and torque the screw to 55 inch lbs. the head of the screw goes in the counter bored side of the yoke.
- 8.) Pull back on the handguard in the direction of the receiver and then torque the two 8-32 screws to 30 inch lbs. Stripped screws are not covered under warranty.

W292S4498 Hill Side Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6756

[www.midwestindustriesinc.com](http://www.midwestindustriesinc.com)