

ALUMINUM

SWISS

K31



CLAMP-ON SCOPE MOUNT

Loosen clamp screw several turns, place mount on the right side of the receiver taking care that the mount is properly seated in the thumb notch before you tighten the screw.

When things look square and in place, tighten screw securely. Do not overtighten.



SWISS PRODUCTS
KALISPELL, MONTANA

MADE IN THE USA



Patent Applied For